



NOMAD

run 3.0

USER'S MANUAL



TABLE OF CONTENTS

ABOUT THE PRODUCT	4
PACKAGE CONTENT.....	5
ASSEMBLY	6
HOW TO USE THE TREADMILL.....	9
HOW TO FOLD AND MOVE THE TREADMILL.....	13
MAINTENANCE AND TROUBLESHOOTING.....	13
EXPLODED VIEW	16
PARTS LIST	17
ORDERING REPLACEMENT PARTS.....	19
LIMITED WARRANTY.....	ERROR! BOOKMARK NOT DEFINED.

IMPORTANT PRECAUTIONS

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons, read all important precautions and instructions in this manual and all warnings on your treadmill before using the treadmill. Nomad Fitness Ltd assumes no responsibility for personal injury or property damage sustained by or through the use of this product.


1. It is the responsibility of the owner to ensure that all users of this treadmill are adequately informed of all warnings and precautions.
2. Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
3. Use the treadmill only as described in this manual.
4. The treadmill is intended for some use only. Do not use the treadmill in any commercial or institutional setting.
5. Keep the treadmill indoors, away from moisture and dust. Do not put the treadmill in a garage or covered patio, or near water.
6. Place the treadmill on a level surface, with at least 8 ft. (2.4 m) of clearance behind it and 2 ft. (0.6 m) on each side. Do not place the treadmill on any surface that blocks air openings. To protect the floor or carpet from damage, place a mat under the treadmill.
7. Keep children under age 12 and pets away from the treadmill at all times.
8. The treadmill should be used only by persons weighing 287 lbs. (130 kg) or less.
9. Never allow more than one person on the treadmill at a time.
10. Wear appropriate exercise clothes while using the treadmill. Do not wear loose clothes that could become caught in the treadmill. Athletic support clothes are recommended for both men and women. Always wear athletic shoes. Never use the treadmill with bare feet, wearing only stockings, or in sandals.
11. Keep fingers, hair, and clothing away from the moving walking belt.
12. Do not operate the treadmill where aerosol products are used or where oxygen is being administered.
13. Plug the power cord into a surge suppressor (not included), and plug the surge suppressor into an appropriate outlet. To avoid overloading the circuit, do not plug other electrical devices, except for low-power devices such as cell phone chargers, into the surge suppressor or into an outlet on the same circuit.

14. Use only a surge suppressor that meets all of the specifications in this manual. Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill. If the control system is damaged, the walking belt may slow, accelerate, or stop unexpectedly, which may result in a fall and serious injury.
15. Keep the power cord and the surge suppressor away from heated surfaces.
16. Never move the walking belt while the power is turned off. Do not operate the treadmill if the power cord or plug is damaged, or if the treadmill is not working properly. (See MAINTENANCE AND TROUBLESHOOTING if the treadmill is not working properly.)
17. Read, understand, and test the emergency stop procedure before using the treadmill (see HOW TO TURN ON THE POWER). Always wear the safety clip while using the treadmill.
18. Always stand on the foot rails when starting or stopping the walking belt. Always hold the handrails while using the treadmill.
19. Note: When a person is walking on the treadmill, the noise level of the treadmill will increase.
20. To avoid static shock wear natural fabric and if there is build-up of static check that the plug and electronics are earthed correctly.
21. The treadmill is capable of high speeds. Adjust the speed in small increments to avoid sudden jumps in speed.
22. The heart rate monitor is not a medical device. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining heart rate trends in general.
23. Never leave the treadmill unattended while it is running. Always remove the key, press the power switch into the off position, and unplug the power cord when the treadmill is not in use.
24. Do not attempt to move the treadmill until it is fully assembled. (See ASSEMBLY , and HOW TO FOLD AND MOVE THE TREADMILL.) You must be able to safely lift 45 lbs. (20 kg) to raise, lower, or move the treadmill.
25. When folding or moving the treadmill, make sure that the storage latch is holding the frame securely in the storage position
26. Never insert any object into any opening on the treadmill.
27. Inspect and properly tighten all parts of the treadmill regularly.
28. DANGER: Always unplug the power cord immediately after use, before cleaning the treadmill, and before performing the maintenance and adjustment procedures described in this manual. Never remove the motor hood unless instructed to do so by an authorized service representative. Servicing other than the procedures in this manual should be performed by an authorized service representative only.
29. Over exercising may result in serious injury or death. If you feel faint, if you become short of breath, or if you experience pain while exercising, stop immediately and cool down.

ABOUT THE PRODUCT

Thank you for selecting the revolutionary Nomad Run 3.0 treadmill. The Nomad Run 3.0 treadmill offers an impressive selection of features designed to make your workouts at home more effective and enjoyable. And when you're not exercising, the unique treadmill can be folded up, requiring less than half the floor space of other treadmills.


For your benefit, read this manual carefully before using the treadmill. If you have questions after reading this manual, please see the front cover of this manual. To help us assist you, please note the product model number before contacting us. Before reading further, please review the drawing below and familiarize yourself with the labelled parts.



Specifications

Model	NOMAD RUN 3.0
Dimensions	1750*800*1300mm
Operating voltage	220V 50/60 Hz
Max User Weight	130kg
Running Area	1300*480mm
Peak Power	3.0HP
Console	7 inch LCD display, Mp3&USB interface, heart rate testing, pre-set programs, touch buttons
Speed range	1-18km/h
Incline	1-12%

PACKAGE CONTENT

<p>Base frame</p> 	<p>Console post x 2</p> 	<p>Console frame</p> 
<p>Console</p> 	<p>Base cover left</p> 	<p>Base cover right</p> 
<p>3.5 mm male-male jack</p> 	<p>Safety key</p> 	<p>Assembly kit</p>

Assembly kit


Description	QTY
Hexagon screw M8*20	14
Hexagon screw M6*15	3
Threaded screw M4*15	6
Allen key 4mm	1
Allen key 5mm	1
Allen key 6mm	1
Multi tool	1
Spanner (two sided)	1
Lubrication bottle	1
User's Manual	1

ASSEMBLY


ATTENTION

- | | |
|---|--|
| <ul style="list-style-type: none">• Assembly requires two persons• Assemble in a clean and level area• Before assembly take parts out but do not dispose of any material until complete | <ul style="list-style-type: none">• Left parts are marked as "L". Right parts are marked as "R"• The treadmill might be covered by light oil to preserve it from rust |
|---|--|


1. Take out the base frame and lay it out on a clean even floor



2. Connect the signal wire in the right post. Place the right and left posts in the base frame. Use 10 x M8*20 screws to fasten the posts to the base frame. Fasten lightly until all screws are aligned before tightening.




3. Connect the signal wire to the console on either side of the upright posts. Fit the console to the posts, be careful not to crush the wire, it should be clear of edges. Use 4 x M8*20 screws to fasten the posts to the console. Fasten lightly until all screws are aligned before tightening.



4. Connect the signal wires between the console base and console. Ensure all wires are cleared away from the edges before lowering console onto base.



5. Remove the 3 x M6*15 screws from the back of the console. Make sure not to discard them. Place the console inside the console base. Ensure not to pinch or crush the signal wires. Use the 3 x M6*15 screws to fasten the console back onto the console base.




6. Place the base frame covers in place. Use the M4*15 screws to fasten the covers to the base frame.



7. Remove the transportation straps holding the base frame and running frame.



Complete Assembly



HOW TO USE THE TREADMILL

CONNECTING THE POWER CORD

Use a Surge Suppressor

The treadmill can be damaged by sudden voltage changes in your home's power. Voltage surges, spikes, and noise interference can result from weather conditions or from other appliances being turned on or off. To decrease the risk of damaging the treadmill, always use a surge suppressor with the treadmill.

Only a surge suppressor that is UL 1449 listed as a transient voltage surge suppressor (TVSS). The surge suppressor must have a UL suppressed voltage rating of 400 volts or less and a minimum surge dissipation of 450 joules. The surge suppressor must also be electrically rated for 240 volts AC and 15 amps. There must be a monitoring light on the surge suppressor to indicate whether it is functioning properly.

Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill and serious injury to users.

Plug in the power cord


The treadmill must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. Plug the power cord into a surge suppressor, and plug the surge suppressor into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

The outlet must be on a nominal 240-volt circuit capable of carrying 15 or more amps. To avoid overloading the circuit, do not plug other electrical devices, except for low power devices such as cell phone chargers, into the surge suppressor or into an outlet on the same circuit. **IMPORTANT:** The treadmill may not be compatible with AFCI-equipped outlets.

HOW TO TURN ON THE POWER

IMPORTANT: If the treadmill has been exposed to cold temperatures, allow it to warm to room temperature before you turn on the power. If you do not do this, you may damage the console displays or other electrical components.

Plug in the power cord. Next, locate the power switch on the treadmill frame near the power cord. Press the power switch into the "on" position.



HOW TO USE THE SAFETY KEY

The treadmill will not function without the safety key being placed on the designated area on the console. The display will indicate "E-07" if the safety key has not been detected.

IMPORTANT: In an emergency, the key can be pulled from the console, causing the walking belt to slow to a stop. Test the clip by carefully taking a few steps backward; if the key is not pulled from the console, adjust the position of the clip.

USING THE CONSOLE



Screen Display:

- Speed (km/h)
- Incline
- Calories / Heart rate
- Time
- Distance (kilometres)



Bottoms:

	Program		Quick Speed
	Mode		Next song
	Incline (+/-)		Previous song
	Quick incline		Stop/play music
	Stop		Increase volume
	Start		Decrease volume
	Speed (+/-)		

HOW TO USE EASY START

1. Insert the safety key.
See the HOW TO TURN ON THE POWER

2. Start the walking belt

Press the Start button and the belt will start to move.

If you press the Start button or the Speed increase button, the walking belt will begin to move at 1 kph. As you exercise, change the speed of the walking belt as desired by pressing the Speed increase and decrease buttons. Each time you press one of the buttons, the speed setting will change by 0.1 kph; if you hold down the button, the speed setting will change rapidly. Note: After you press the button, it may take a moment for the walking belt to reach the selected speed setting.

If you press one of the numbered speed buttons, the walking belt will gradually change speed until it reaches the selected speed setting. To select a speed setting that includes a decimal—such as 3.1 kph—press two numbered buttons in succession. For example, to select a speed setting of 3 kph, then immediately press button 5.

To stop the walking belt, press the Stop button. The time will begin to flash in the display. To restart the walking belt, press the Start button or the Speed increase button.

3. Change the incline of the treadmill as desired. To change the incline of the treadmill, press the Incline increase and decrease buttons or one of the numbered incline buttons. Each time you press one of the buttons, the treadmill will gradually adjust to the selected incline setting.
4. The Calorie tab will show the approximate number of calories you have burned. The height of each segment represents the number of calories burned during that segment. When the Calorie tab is selected, the calorie display will show the approximate number of calories burned per hour.
5. Measure your heart rate if desired. You can measure your heart rate using the handgrip heart rate monitor.
6. To measure your heart rate, stand on the foot rails and hold the pulse bar with your palms on the metal contacts; avoid moving your hands. When your pulse is detected, a heart symbol will appear, and then your heart rate will be shown. For the most accurate heart rate reading, continue to hold the contacts for about 15 seconds.
7. When you are finished exercising, remove the safety key from the console. Step onto the foot rails, press the Stop button, and adjust the incline of the treadmill to zero. The incline must be at zero or you may damage the treadmill. If the machine is turned off and you can still hear the motor it is the incline coming down, wait for the noise to stop before switching it off at the wall. It is now ready to be folded away in the storage position. Next, remove the key from the console and put it in a secure place. When you are finished using the treadmill, press the power switch into the off position and unplug the power cord. **IMPORTANT:** If you do not do this, the treadmill's electrical components may wear prematurely.

HOW TO USE THE MODE FUNCTIONALITY

The mode functionality enables you to set target goals for time, distance and calories which you want to work towards.

1. Insert the safety key.
See HOW TO TURN ON THE POWER (see page 9)
2. Select MODE
Push the MODE button until the goal type you want set flashes in the console screen.
3. Set the target
The default, min and max values are provided below:

Mode Type	Default	Minimum Value	Maximum Value
Time	30 mins	5 mins	99 mins
Distance	1 km	0.5 km	99.9 km
Calories	50 kcal	10 kcal	999 kcal

4. Start the walking belt
5. Press the Start button and the belt will start to move. See page 11.

HOW TO USE THE PRESET PROGRAMS

1. Insert the safety key
See HOW TO TURN ON THE POWER (see page 9)
2. Select the pre-set program
Use the SPEED +/- buttons to select one of the 8 pre-set programs and press the Start button. The programs are graphically illustrated on the console next to the screen. Set the target time by using the SPEED +/- button.
3. Start the walking belt
Press the Start button to start the workout. A moment after you press the button, the treadmill will automatically adjust to the first speed and incline settings of the workout. Hold the handrails and begin walking.

Each workout is divided into segments. One speed setting and one incline setting are programmed for each segment. Note: The same speed setting and/or incline setting may be programmed for consecutive segments.

If the speed or incline setting is too high or too low at any time during the workout, you can manually override the setting by pressing the Speed or Incline buttons; however, when the next segment of the workout begins, the treadmill will automatically adjust to the speed and incline settings for the next segment.

4. Measure your heart rate if desired. You can measure your heart rate using the handgrip heart rate monitor.
5. When you are finished exercising, remove the safety key from the console. See page 11.

HOW TO FOLD AND MOVE THE TREADMILL

HOW TO FOLD THE TREADMILL

To avoid damaging the treadmill, adjust the incline to zero before you fold the treadmill. Then, remove the key and unplug the power cord. CAUTION: You must be able to safely lift 45 lbs. (20 kg) to raise, lower, or move the treadmill.

1. Hold the end covers firmly in the location shown by the arrow below. CAUTION: Do not hold the frame by the plastic foot rails. Bend your legs and keep your back straight.
2. Raise the frame until the lock tube locks in the storage position. CAUTION: Make sure that the locking tube locks. To protect the floor or carpet, place a mat under the treadmill. Keep the treadmill out of direct sunlight. Do not leave the treadmill in the storage position in temperatures above 30° C.




HOW TO MOVE THE TREADMILL

Before moving the treadmill, fold it as described at the left. CAUTION: Make sure that the locking tube is locked in the storage position. Moving the treadmill may require two people. Hold the handrails with both hands and carefully push the treadmill to the desired location. CAUTION: Do not pull on the frame, and do not move the treadmill over an uneven surface.

HOW TO LOWER THE TREADMILL

1. Push the upper end of the frame forward, and gently press the upper part of the storage latch with your foot at the same time.
2. While pressing the storage latch with your foot, pull the upper end of the frame toward yourself.
3. Step back and let the frame lower to the floor.



MAINTENANCE AND TROUBLESHOOTING

CLEANING

Regularly clean the treadmill and keep the walking belt clean and dry. First, press the power switch into the off position and unplug the power cord. Wipe exterior parts of the treadmill with a damp cloth and a small amount of mild soap. IMPORTANT: Do not spray liquids directly onto the treadmill. To avoid damage to the console, keep liquids away from the console. Then, thoroughly dry the treadmill with a soft towel.

BELT LUBRICATION


The walking belt is lubricated with a high-performance lubricant to reduce the friction between the walking belt and the running board. If the lubrication is inadequate the belt will not operate smoothly. Remove the key and UNPLUG THE POWER CORD. Run your finger

along the underside of the belt. If there is no lubricant residue on your fingers lubrication is needed.

To add lubrication to the walking belt. Remove the key and UNPLUG THE POWER CORD. Lift the walking belt in the centre from the running board. Add 10 ml of lubricant to the running board. Turn the treadmill on using easy mode and let it run for 10 mins at 12 kph. Repeat the process until there is an even film of lubricant on the walking belt

ADJUSTING THE WALKING BELT

If the walking belt is off centre, or slowing when walked on or slips, remove the key and UNPLUG THE POWER CORD. If the walking belt has shifted to the left, use the hex key to turn the left idler roller screw clockwise $\frac{1}{2}$ of a turn; if the walking belt has shifted to the right, turn the left idler roller screw counter clockwise $\frac{1}{2}$ of a turn. Be careful not to overtighten the walking belt. Then, plug in the power cord, insert the key, and run the treadmill for a few minutes. Repeat until the walking belt is centred.



If the walking belt slips when walked on, first remove the key and UNPLUG THE POWER CORD. Using the hex key, turn both idler roller screws clockwise, $\frac{1}{4}$ of a turn. When the walking belt is correctly tightened, you should be able to lift each edge of the walking belt 2 to 3 inches (5 to 7 cm) off the walking platform. Be careful to keep the walking belt centred. Then, plug in the power cord, insert the key, and carefully walk on the treadmill for a few minutes. Repeat until the walking belt is properly tightened.


If the walking belt is overtightened, treadmill performance may decrease and the walking belt may become damaged. Remove the key and UNPLUG THE POWER CORD. Using the hex key, turn both idler roller screws counter clockwise, $\frac{1}{4}$ of a turn. When the walking belt is properly tightened, you should be able to lift each edge of the walking belt 2 to 3 inches. (5 to 7 cm) off the walking platform. Be careful to keep the walking belt centred. Then, plug in the power cord, insert the key, and run the treadmill for a few minutes. Repeat until the walking belt is properly tightened.

TROUBLE SHOOTING

Symptom	Possible Causes	Solution
Console screen not displaying anything	The power cord is not connected	Connect power cord
	The power switch is off	Turn on power switch
	A problem with the communication wire	Connect or replace communication wire
Treadmill walking belt not working smoothly	Walking belt is too tight	Loosen walking belt
	Walking belt is too loose	Tighten walking belt
	Obstruction	Remove obstruction

Error Codes	E01 - Communication failure	Communication wire damaged or not connected	Replace or connect communication wire
	E13 - Communication failure	Communication wire damaged or not connected	Replace or connect communication wire
	E07 - Safety Key	Safety key is not in place	Place safety key on allocated console area
	E02 - Stall protection	Input voltage is low	Check input (plug) voltage
	E03 - No speedo sensor signal	Speedo sensor wire damaged or not connected	Replace or connect sensor wire
	E04 - Incline error	Incline motor or communication wire damaged or not connected	Replace or connect communication wire
		Incline motor is broken	Replace the incline motor
	E05 - Over current protection	Over currents has occur	Turn the treadmill off and on
		Walking belt drive blocked or stuck	Remove blockage or adjust drive system
		Motor is shorting	Replace the motor
		Motor is not spinning	Input current too low
	E08 - Memory error (24C02)	Error with memory IC	Check memory IC (next to the "on" switch)
	E10 - Peak power error	Motor belt tension too high	Loosen motor tension belt
		Motor error	Replace motor
		Walking belt drive blocked or stuck	Remove blockage or adjust drive system
	E06 - Motor error	Connections damaged or loose	Replace or tighten connections
Motor is shorting		Replace motor	
Motor is not spinning		Input current too low	

EXPLODED VIEW



PARTS LIST

No. Part	Description	QTY	No. Part	Description	QTY
1	Base frame	1	43	Side rail	2
2	Main frame	1	44	Motor	1
3	Incline frame	1	45	Pad	2
4	Connection frame	1	46	Incline motor	1
5	Left console post	1	47	Pad left	1
6	Right console post	1	48	Pad right	1
7	Console frame	1	49	Running board pad	4
8	Console small frame	1	50	Motor cover	1
9	Motor base	1	51	End cover left	1
10	Console screen	1	52	End cover right	1
11	M6*15 Hexagon screws	3	53	Frame cover left	1
12	ST4.2*16 Recessed tapped screw	35	54	Frame cover right	1
13	M10*60 Hexagon screws	1	55	Console cover top	1
14	M10*45 Hexagon screws	1	56	Console cover bottom	1
15	M10*25 Hexagon screws	4	57	Console screen cover	1
16	M10*30 Hexagon screws	2	58	Console screen cover back	1
17	M8*55* 20 Hexagon half threaded screws	3	59	Handle left	1
18	M8*40* 20 Hexagon half threaded screws	2	60	Handle right	1
19	M8*30* 20 Hexagon half threaded screws	1	61	Bottle holder left	1
20	M8*20 Hexagon screws	14	62	Bottle holder right	1
21	M8*12 Hexagon coarse threaded screw	2	63	20x12.5x6.5 Washer	8
22	M8*105 Hexagon screws	1	64	Air outlet	1
23	M8*75 Hexagon screws	3	65	Wheel cover	2
24	M6*50 Counter sunk screw	4	66	Pulse sensor	2
25	M6*30 Counter sunk screw	2	67	Gas strut	1
26	M5*10 Counter sunk screw	11	68	Rubber protection	4
27	M5*15 Counter sunk screw	8	69	Wheel	2
28	M4*15 Screw	8	70	Rubber pad	6

No. Part	Description	QTY	No. Part	Description	QTY
29	M4*10 Counter sunk screw	5	71	Wheel	2
30	ST3 .7*40 Counter sunk screw	4	72	Spacer	2
31	ST4 .2*16 Counter sunk screw	8	73	Spacer	2
32	M10 Nut	12	74	Clip	1
33	M8 Nut	6	75	R shape clamp	3
34	F 10 Flat washer	12	76	Belt	1
35	F 8 Flat washer	13	77	f 3 5*f 21*13 Magnetic ring	2
36	F 10 Spring washer	4	78	250V/10A Fuse	1
37	F 8 Spring washer	2	79	15A Switch	1
38	F 5 Lock washer	3	80	Bracket	1
39	Front roller	1	81	800mm Cable	1
40	Rear roller	1	82	1200mm Cable	1
41	Running board	1	83	700mm Cable	1
42	Walking belt	1			

ORDERING REPLACEMENT PARTS

To order replacement parts, please see the front cover of this manual. To help us assist you, be prepared to provide the following information when contacting us:

- the model number and serial number of the product
- the name of the product (see the front cover of this manual)
- the key number and description of the replacement part(s) (see the PART LIST and the EXPLODED DRAWING near the end of this manual)

LIMITED WARRANTY

Offered by NOMAD FITNESS LTD ("Nomad")

All Nomad products are warranted for use within a private, domestic, non-fee-paying environment. The warranties are non-transferable as they are only valid for the original owner (purchaser) of the equipment. The warranty will not apply if the product is used other than domestic use, is not operated according to the operating manual supplied or the product leaves the United Kingdom. The warranties are subject to the product been used as intended and maintained and serviced as prescribed. and abuse, inappropriate use will be excluded.

Nomad warrants this product to be free from defects in workmanship and material,

The STANDARD WARRANTY is for a period of 12 months but an EXTENDED WARRANTY is also offered. The STANDARD WARRANTY includes the frame of the equipment in question with its motor. The labour applicable here is also included.

To qualify for the EXTENDED WARRANTY the product purchased needs to be registered by completing the warranty registration form included herein and this needs to reach the official offices of Nomad within 30 days after purchase. The extended warranty fee of £90 is payable for a further 18 months and includes the frame of the equipment and the motor.

All repairs or replacement needs to be authorized by Nomad. Nomad will not reimburse for any transport or courier service and will arrange for the product to be collected either by Nomad or a third party. The warranty is related to the delivery address of the client and additional collection and delivery fees may be applicable due to the extended distance. The client consent to Nomad doing an assessment and repair if required on the premises where the product is located. The client or any other party may not conduct any repair work on the machine other than the normal service and maintenance as per the operating manual supplied. The warranty specifically excludes cases where the product was altered, modified, damaged, repaired by any party other than Nomad. The warranty does not cover damaged caused by fire, lightning, accidents, water damage (including humidity), pollution (such as fumes, dust and chemicals) or earth quakes.

The process to act on the warranty include the notification of Nomad which include the nature of the problem encountered and the serial number of the equipment. If it is a minor repair Nomad may guide the client to rectify the matter. A call charge of £50 will be levied to collect and deliver the product but should if the product was identified with a defect, this charge will be reimbursed about when the product is fixed and delivered back to the customer.

Nomad has the right to replace the product with a similar product in terms of condition and specifications.

Nomad is not responsible or liable expense, liability, loss, or proceeding whatsoever in respect of any personal injury related to the equipment or an any damages, economic loss including loss of revenue, loss of enjoyment or training or any other consequential damages that are permitted by law.